



VITREX (PTY) LTD

Tel: +27 11 826-6057/8/9 Fax: +27 11 823-1641

PO Box 13101, Witfield 1467, South Africa

9 Jansen Road, Jet Park, Boksburg

email: vitrex@vitrex.co.za

www.vitrex.co.za



CLEANING and MAINTENANCE

EuroSan Enamel Steel Baths and Shower Trays

(Document Reference CC/CLEAN/EUROSAN/01 Rev. 0 March 2010)

(E&OE - Document and content subject to change without prior notice)

We are proud to guarantee our EuroSan vitreous enamel steel surfaces, in respect of normal usage, to perform specifically to the functions for which they were intended and against deterioration or failure of component vitreous enamelled parts for a period of fifteen (15) years.

We recommend that the enamel surface be cleaned on a regular basis with a very light detergent solution (i.e. dish washing soap, preferably one with Anti-bacterial properties, and warm water) applied with a soft sponge and lightly rinsed down.

In general, ammonia based cleaners, such as Handy Andy, should be avoided as they tend to dull the surface and can leave a residue behind.

In the case of more stubborn marks, we would suggest first the use of either Paint Thinners or Alcohol followed by a final cleaning down as described above.

The use of any acid based solvents, rubbing compounds and scourers should be avoided.



Member of the Institute
of Vitreous Enamellers (IVE)

ISO 9001:2000 accredited
Quality Management System



Directors

CFG Cottino M.Sc.Eng. (Civil) (Wits), KD Holzapfel, R Narotzky ACIS (Managing), RF Vollmer, B Yawitch B. Arch. (Wits) (Chairman)

Reg. No. 83/13778/07